

Bravo 502

Numeric Pagers

Real-Time Communications and Connectivity When Every Second Counts

- » Up to 18 Personal Memory Slots
- » Protect up to 10 Messages
- » Individual Message Delete or Delete-All
- » Backlit
- » Private Time
- » Time and Date Display
- » Alert Type: Melody, Chirp, Vibrate, Vibrate-Chirp, Silent
- » Battery Low Indicator and Alert
- » Out-of-Range Indicator and Alert



Top Mount, UL-Rated Numeric Pager

The Bravo 502 numeric pager is an intrinsically safe, top mount pager ideal for applications where ease-of-use and safety are important.

Easily read whilst still attached to the hip of the wearer, the Bravo 502 reduces the chance of the pager being misplaced, a critical issue during an emergency.

Selectable Alert Types

Providing a high level of flexibility to any communications solution, the Bravo 502 pager features five selectable alert tones. Along with the melody tone setting, the Bravo 502 features Chirp, Vibrate, Vibrate and chirp and Silent.

Unread Message Reminder

For those times when everything is moving at a mile a second, the Bravo 502 numeric pager features an unread message reminder - ensuring that you won't forget a message, even when you don't have the time to read it right away.

Out-of-Range Indicator and Alert

When a user takes a Bravo 502 pager out of the range of the communications system, the unit can be configured to sound an alert. This simple and efficient feature ensures that staff carrying pagers are aware when they are out of range.

Get the Message

The Bravo 502 pager provides memory slots for up to 18 personal messages. In addition, users can protect a total of 10 messages from deletion.

When the pager memory is full, the Bravo 502 will alert the user - ensuring there is enough memory available for incoming messages.

Continuous Message Indicator

When an incoming message requires more than the available characters of a single message, its content will be broken into a continuous message of two or more screens. Where this occurs, the Bravo 502 alerts the user with a graphical continuous message symbol.

To learn more about CommtechWireless products and solutions, visit Amcomsoftware.com or call 1.800.852.8935 to speak to our experts about a communications solution for your facility.

Bravo 502 Pagers

TECHNICAL SPECIFICATIONS

Bravo 502 Pagers

Equipment Type	BR502	
Frequency	VHF (135-175MHz) UHF (452-468Mhz) 900MHz (929-932Mhz)	
Code Format	POCSAG/ FLEX	
Channel Spacing	25KHz	
Frequency Deviation	±4.5KHz	
Paging Sensitivity	-107 dBm-104 dBm	
EIA Selectivity	55 dB	40 dB
EIA Serious and Image	50 dB	40 dB
IM Rejection	50 dB	40 dB
Data Transmission Rate	512 bps 1200bps 2400bps	1600bps 3200bps 6400bps
FM Modulation Stability	<2.5 ppm	
Temperature / Humidity	-10oC (-4oF) to 50oC 5oC to 40oC	
Weight (including battery)	45g (2.29 oz)	
Battery Type	1 x Alkaline AAA	
Alert Tone Loudness	75 dB @12 inches	
Dimensions (without holster)	64 (L) x 43 (W) x 19.5 (H)mm 2.5 (L) x 1.7 (W) x 0.8 (H) inches	



Asia Pacific

PO Box 1037
OPDC 6916
PERTH, Western Australia
Phone: +61 8 6240 0000
Fax: +61 8 6240 0001

United States

8301 Cypress Plaza Drive, Suite 105
JACKSONVILLE, FL
32256-4416
Phone: +1 904 281 0073
Fax: +1 904 281 0074

Europe Office

Ladegaardsvej 2
DK-7100 Vejle
DENMARK
Phone: +45 70 27 87 10
Fax: +45 70 27 87 19